

HƯỚNG DẪN SỬ DỤNG VÀ VẬN HÀNH CÂN ĐIỆN TỬ FRJ 600 g**HƯỚNG DẪN SỬ DỤNG VÀ VẬN HÀNH CÂN ĐIỆN TỬ FRJ 600 g**

(CÂN ĐIỆN TỬ THỊNH PHÁT biên soạn dựa theo tài liệu hãng).

- Cân điện tử FRJ do Fuzhou FURI Electronics Co.Ltd sản xuất được Công ty Cổ Phần Cân Điện Tử Thịnh Phát có trụ sở chính tại số 57 Đường Nguyễn Văn Thương, Phường 25, Quận Bình Thạnh, TP.Hồ Chí Minh nhập khẩu và phân phối.

Các bước chuẩn bị thiết bị.

- Đặt cân ở vị trí tránh gió, tránh luồng máy lạnh, tránh cửa ra vào.
- Sử dụng cân đúng nguồn điện và nguồn phải ổn định.
- Quả cân chuẩn yêu cầu quả F1 thì tốt nhất.

Hướng dẫn cách cân.

- Mở cân bằng cách nhấn phím **ON/OFF** (phím cơ bên hông phía dưới cân), chờ khi cân hiển thị 0.0g.
- Đặt vật cân lên chính giữa đĩa cân và đọc kết quả.

Trừ bì.

- Khi cân ở trạng thái 0.0 g, đặt bì lên bàn cân rồi nhấn phím **TARE** cân tự động trừ bì và hiển thị 0.0 g. Đặt mẫu vào bì và cân bình thường.
- Lưu ý: Khi lấy bì ra khỏi cân, nhớ nhấn phím **TARE** để cân về trạng thái ban đầu trước khi tắt cân.

Ý nghĩa các phím chức năng.

- Phím **ON/OFF** phím tắt mở cân.
- Phím **ZERO** phím trả cân về điểm 0.
- Phím **TARE** phím trừ bì.
- Phím **MODE** phím đếm mẫu.
- Phím **N.W/G.W** phím lấy mẫu đếm.

Đèn báo.

Khi đèn báo sáng ở đâu thì cân hiển thị ở đó.

1. Đèn báo STABLE cân đang ở chế độ ổn định.
2. Đèn báo ZERO cân đang ở chế độ 0 tải, cân đang ở chế độ trừ bì.
3. Đèn báo kg: Cân đang ở đơn vị “kg”
4. Đèn báo g: Cân đang ở đơn vị “g”
5. Đèn báo lb: Cân đang ở đơn vị “lb”
6. Đèn báo tl.T: Cân đang ở đơn vị “tl.T”.

Hướng dẫn hiệu chuẩn cân điện tử FRJ

Chuẩn bị quả cân F1 tương ứng với cân cần hiệu chuẩn.

1. Trước khi vào hiệu chuẩn cân, mở cân bằng phím **[ON/OFF]** đợi 1 phút cho cân ổn định.
2. Nhấn giữ phím **Z** đợi màn hình hiển thị số nội, tiếp tục nhấn phím **Z** cân hiện thị trọng lượng cần hiệu chuẩn chớp chớp số, ta bỏ trọng lượng cần hiệu chuẩn lên đĩa cân, tiếp tục nhấn phím **Z** cân hiện thị **CAL** sau đó cân tự động nhận trọng lượng vừa hiệu chuẩn.
3. Nhấn phím **[ON/OFF]** tắt nguồn cân, mở cân lại bằng phím **[ON/OFF]** kiểm tra lại xem cân hiệu chuẩn đúng chưa, bằng cách bỏ quả cân vừa hiệu chuẩn lên cân để kiểm tra lại nếu đúng thì cân hiệu chuẩn thành công.
4. Vào chế độ cân bình thường.


Vệ sinh bảo trì định kỳ cân.

- Ngắt nguồn điện trước khi vệ sinh cân, chắc chắn không có chất lỏng bên trong, vệ sinh cân bằng khăn ẩm hoặc sử dụng các chất tẩy rửa nhẹ. Không sử dụng cân trong môi trường dung môi, hóa chất khắc nghiệt.
- Khi có sự cố vui lòng liên hệ ngay điện thoại: (028) 62.888.666 di động 0915.999.111 địa chỉ trụ sở chính tại số 57 Đường Nguyễn Văn Thương, Phường 25, Quận Bình Thạnh, TP.Hồ Chí Minh.

COMPACT SCALE

FRJ SERIES

INSTRUCTION MANUAL



SAFETY PRECAUTIONS

All safety messages are identified by the words "**WARNING**" and "**CAUTION**". These words mean the following:

⚠ WARNING	Important information to alert you to a situation that might cause serious injury and damage to your property if instructions are not followed.
⚠ CAUTION	Important information that tells how to prevent damage to the equipment.

When using the scale, the following safety precautions should always be followed.

⚠ WARNING

Use only the correct AC adaptor with the scale. Other adaptors may cause permanent electrical damage.

⚠ CAUTION

Avoid placing the scale in direct sunlight, this may cause discoloration or malfunction.

Replace all batteries at the same time – Do not replace only a portion of the 4 batteries as this may cause a malfunction.

If the scale is not to be used for a long period of time, remove all batteries from the battery compartment to avoid leakage, which may cause damage to this scale.

PARTS DESCRIPTION

► LIGHT SIDE

AC adaptor
Socket

► TOP

Weighing container

The weighing container is place
on the scale.

Display

ON/OFF key
Turns the scale
Power on/off.

ZERO key
Sets display to zero(Turn the scale power on)

TARE key
Subtracts weight of a container.

MODE key
Changes weighing units

N.W/G.W key
Switch N.W/G.W(or set Pcs) key

► BOTTOM

Battery compartment cover

Batteries
Batteries are not included

Battery compartment

► DISPLAY

ZERO indicator
Indicates when the scale zero is correct.

TARE indicator
Indicates when the reading is stable.

 **Low battery indicator**

Weighing unit




PREPARATION

1.Installing batteries/Connecting the AC adaptor

Batteries

Battery
compartment cover




Remove the battery compartment cover and insert four batteries(R6P/LR6 /AAAsize) into the battery compartment, taking extreme care that the polarities plus and minus is observed.



R6P/LR6/AAA size
Dry batteries.
(batteries are not included)

AC adaptor (optional)

AC adaptor
socket



Plug the AC adaptor to the AC adaptor socket on the side. The AC input requirement could be 110,120,220,230 or 240Volts (50/60Hz) depending on the area where used, so please verify that the adaptor is correct

2.Setting up the scale

⚠ CAUTION

Avoid installing the scale in direct sunlight, that may cause discoloration or malfunctions. Place your scale on a firm weighing table so that the scale is level. (The scale will not perform accurately when it is not level.)

Place the scale on the firm surface that is flat and level for an accurate weighing.

WEIGHING AND COUNTING

Before weighing and counting

Whenever possible, please allow the balance to warm up for 10 minutes after first turning to power on, so that the balance will function properly and accurately.

Error messages

EEEE: Overload

: Low battery

Calibration may be required before weighing.

Read "CALIBRATION" first and if necessary, calibrate your scale for accurate weighing.

Weighing procedures

1. Press [ON/OFF] to turn on the scale.

When power is turned on, all display segments appear on LCD for a few seconds and finally "0" will appear on the display.

2. Select the weighing unit with [MODE].

Press [MODE] to select a weighing unit, eg. "g" and etc .

Once the unit has been selected, the selected unit will be displayed to the weight value.

3. Start weighing

Verify the reading is "0". If not, press [ZERO] to display "0".

Place objects in the weighing container to weigh.

The weighing value is displayed.

Counting procedures

1. Press [ON/OFF] to turn on the scale.

When power is turned on, all display segments appear on LCD for a few seconds and finally "0" will appear on the display.

2. Start counting

verify the reading is "0" ,if not, press [ZERO] key to display "0".

Place the certain numbers of sample in the container(numbers of sample=10、20、50or100), total weigh is displayed.

Press[MODE] key to select the counting mode.(e.g. count)

Set the certain numbers of sample thought press [NW/GW] key(the certain numbers of sample=10、20、50or100), then press [MODE] key, the display will show "CAL", after 1 second, set the certain numbers of sample are displayed.

Place the unknown numbers of sample in the container, the total numbers is displayed.

3. Return to weighing mode

Press[MODE] key, the scale return to the weighing mode.

NOTE: the weigh of unit sample > 10e.

CALIBRATION

When to calibrate

Calibration may be required when it is initially installed, if the scale is moved to a substantial distance.

This is necessary because the weight of a mass in one location is not necessarily the same in another location. Also, with time and use, mechanical deviations may occur.

How to calibrate

1. Before entering calibration mode, press **[ON/OFF]** to turn the power on for 1minutes.
2. **Enter calibration mode**
Press **[ON/OFF]** to turn the power off. Press and hold **[ZERO]**, after 3~5 seconds the display will show the A/D value.
3. **Calibration by the weight**
Wait for 3 seconds, Press **[ZERO]** the display will show "**2Ero**", then the display will return to full weight value.
4. Place the full weight (eg.5000g for FRJ5000) in container. then press **[ZERO]**, the display will show "CAL", then the displayed will return to "PASS", Now calibration is finished.
5. Press **[ON/OFF]**, turn off the power, press **[ON/OFF]** turn on the power again, place full weight (eg.5000g for FRJ5000) in the container to make sure whether weighing is correct, if not, repeat steps 2-5.
6. **Return to weighing mode**
Press **[ON/OFF]** to turn the power off. Press **[ON/OFF]** again to turn on the power and the scale return to the weighing mode.

FEATURES

- Auto shut off
- Auto calibration
- Auto zero tracking
- g/oz/lb or g/oz/dwtconversion(optional)
- Low battery indication
- Large container weighing
- Large LCD (5.5digits 15 mm high)
- Counting function
- Net weight/Gross weight indication
- 1/2000,1/3000&1/5000 division available